



MANAGING & MONITORING THE SG SERIES UPS FROM ANYWHERE IN THE WORLD OVER THE INTERNET USING DSL

Requirements:

1. DSL Connection
 - a. DSL must have fixed or static IP addresses
 - b. DSL router connected to an Ethernet hub.
 - c. Gateway IP address for router.
 - d. Dedicated IP address(s) for the USHA SNMP/HTTP adaptor(s).
2. Falcon SG Series UPS
 - a. Optional USHA SNMP/HTTP adaptor
 - b. Ethernet cable.
 - c. Modem communications program such as Hyperterminal.
 - d. Supplied RS-232 cable.

